



## HLX Firmware Update Procedure

### Updating Version 2.0.0 or later to Version 2.1.0

**WARNING:** If the HLX has firmware version 1.3.0 or earlier, call Audio Authority.

1. Download the firmware update from [audioauthority.com](http://audioauthority.com) and copy the files to a USB drive\*.
2. Insert the drive in the USB port on the rear panel of the HLX.
3. Find Firmware Update in the HLX menu and select HLX\_V210.HFF file.
4. The expansion cards are updated, then the system reboots and begins the system card update.
5. The HLX reboots again when the update is complete. Check the Firmware Versions menu item to make sure all system and card firmware versions are 2.1.0. The bootloader is 2.0.0.

### Updating Older Bootloader Versions

If the **system card** bootloader is less than version 2.0.0 there are three separate update operations that must be accomplished in the correct sequence. Call Audio Authority Technical Support for instructions.

\* Most USB drives are compatible with the HLX, however, if you experience difficulties with the update, try again using a different USB drive.