

# User Manual

## Model 1810 RS-232 to CEC Adapter



Audio  Authority®

## Introduction

The Model 1810 is designed to translate serial commands to CEC commands for control of devices such as televisions, soundbars, and receivers. It may be connected directly to the HDMI input of any device, or it may be connected to multiple devices via a compatible HDMI distribution amplifier that passes CEC commands.



## Connections

The adapter requires an RJ-45 to null modem cable (included) to connect to the serial output device. Any good quality HDMI cable is adequate for connection to HDMI devices. Keep cable lengths as short as possible.

Power is provided via a 12V DC adapter (included) with a micro USB connector.

## Commands

RS-232 CEC Commands (9600 baud) all begin with “CEC”, followed by the hexadecimal CEC command, all commands should be appended with a carriage return <CR>. You may use this CEC command builder/translator (<http://www.cec-o-matic.com/>) to generate the hexadecimal CEC commands.

### Example Commands

Command	Example
Receiver/Soundbar Volume Up	CEC05:44:41
TV Power On	CEC10:04
TV Power On	CEC10:0D
TV Power On	CEC10:44:40
TV Power On	CEC10:44:6D
All Devices Standby	CEC1F:36

Notice that there are multiple commands for Power On. Some devices accept certain commands, some devices accept all forms. To request status updates from CEC devices, send queries as shown. Responses return as CEC Hex Commands.

### Example Queries

Query	Response
Request Soundbar Power Status	CEC05:8F
Soundbar Power Status is On	50:90:00

## Troubleshooting

- Check for loose or damaged cables. Use strain relief where appropriate.
- Make certain that each HDMI device has CEC activated.

If you experience difficulties, call Audio Authority Support at 800-322-8346 M-F 8:30 AM to 5:00 PM EDT.



2048 Mercer Road, Lexington, KY 40511-1071 USA  
800-322-8346 • 859-233-4599 • Fax: 859-233-4510  
support@audioauthority.com • www.audioauthority.com